

OpenHPI for HP ProLiant Rack Mount Server Developers Guide

Published: November 2009
Edition: 2.0



The information in this document is subject to change without notice. Hewlett-Packard makes no warranty of any kind with regard to this manual, including, but not limited to, the implied warranties of merchantability and fitness for a particular purpose. Hewlett-Packard shall not be held liable for errors contained herein or direct, indirect, special, incidental or consequential damages in connection with the furnishing, performance, or use of this material.

Table of Contents

Introduction.....	7
Intended Audience.....	7
Additional Resources.....	7
Typographic Conventions.....	8
HP Encourages Your Comments.....	8
Overview.....	8
Supported Systems.....	9
Unsupported Systems.....	9
OpenHPI Releases	9
System Requirements.....	9
Installation Requirements.....	9
Firmware Requirements.....	10
Configuring the iLO2 RIBCL Plug-In.....	10
Setting the iLO2 User Name and Password.....	10
Modifying the iLO2 RIBCL Section in the OpenHPI Configuration File.....	10
HP ProLiant Server Resources.....	11
HP ProLiant Server Model Differences.....	11
RPT Mapping and HP ProLiant Server Entity Types.....	11
System Chassis Resources.....	13
Processor Resources.....	13
Memory Resources.....	13
Power Supply Resources.....	13
Power Module (VRM) Resources.....	13
Fan Resources.....	13
Resource RDR Mappings.....	14
HP ProLiant Chassis RDRs.....	14
Chassis Controls	14
Chassis Inventory.....	15
Example Chassis IDR Output.....	16
Chassis Sensors.....	16
Processor RDRs.....	17
Example Processor IDR Output.....	17
Memory RDRs.....	17
Example Memory IDR Output.....	17
Power Supply RDRs.....	18
Fan (Cooling Device).....	18
Voltage Regulator Module (VRM) RDRs.....	18
Sample hptop Output for Supported Servers.....	18
Hot Swap Operations.....	26
FRU Non-Managed Hot Swap	26
Resource Events and Hot Swap Events	26
Resource Event Log.....	27
OpenHPI Domain Event Log.....	27
OpenHPI Domain Alarm Table.....	28
OpenHPI iLO2 RIBCL Plug-In Supported APIs.....	28

List of Figures

1	Unmanaged Hot Swap Model.....	26
---	-------------------------------	----

List of Tables

1	HP ProLiant Model Resource Differences.....	11
2	RPT Mappings.....	12
3	HP ProLiant Server Entity Type Definitions.....	12
4	Entity Path Examples.....	12
5	Supported Controls.....	15
6	Chassis Control Summary.....	15
7	Chassis Inventory Fields.....	15
8	Chassis Sensors HPI Data.....	16
9	Chassis Sensor Values.....	16
10	Processor Inventory Field.....	17
11	Memory Inventory Fields.....	17
12	Sample hptop Output.....	19
13	Events Generated by ProLiant Resources.....	27
14	Supported APIs for iLO2 RIBCL Plug-In.....	28

Introduction

The OpenHPI Developer's Guide for the HP ProLiant Rack Mount Server describes how to install and configure the iLO2 RIBCL plug-in and provides a product overview, and information on resource mappings and event processing.

Intended Audience

This document is intended for application developers, programmers, and database administrators who are responsible for developing, testing, administering and maintaining OpenHPI enablement on HP ProLiant Rack Mount servers using the iLO2 RIBCL plug-in.

Additional Resources

For more information about iLO2, including the *HP Integrated Lights-Out 2 User Guide* located at:

<http://www.hp.com/servers/lights-out>

Typographic Conventions

This document uses the following typographic conventions.

Command	A command name or qualified command phrase.
ComputerOut	Text displayed by the computer.
Ctrl-x	A key sequence. A sequence such as Ctrl-x indicates that you must hold down the key labeled Ctrl while you press another key or button.
ENVIRONVAR	The name of an environment variable, for example, PATH.
[ERRORNAME]	The name of an error, usually returned in the <code>errno</code> variable.
Key	The name of a keyboard key. Return and Enter both refer to the same key.
Term	The defined use of an important word or phrase.
UserInput	Commands and other text that you type.
<i>VARIABLE</i>	The name of a placeholder in a command, function, or other syntax display that you replace with an actual value.
\ (<i>continuation character</i>)	A backslash (\) at the end of a line of code (such as a command) indicates that the following line of code is contiguous, and you must not insert a line break. This convention facilitates the typesetting of long lines of code examples on a printed page. If you cut and paste sample code from this publication, ensure that you remove backslash characters at line endings.
...	The preceding element can be repeated an arbitrary number of times.
	Separates items in a list of choices.

HP Encourages Your Comments

HP encourages your comments concerning this document. We are committed to providing documentation that meets your needs. Send any errors found, suggestions for improvement, or compliments to:

docsfeedback@hp.com

Include the document title, and any comment, error found, or suggestion for improvement you have concerning this document.

Overview

OpenHPI provides an open source implementation of the Service Availability Forum (SAF) Hardware Platform Interface (HPI). HPI provides an interface for managing computer hardware like the HP ProLiant Rack Mount Server. The HP ProLiant Rack Mount Server requires an OpenHPI “plug-in” to support OpenHPI on its hardware. HP has developed the iLO2 RIBCL plug-in to allow access to the HP ProLiant Rack Mount Server.

The iLO2 RIBCL plug-in is an interface to HP ProLiant Rack Mount servers, which use Remote Insight Board Command Language (RIBCL) to communicate with the on-board Integrated Lights-Out 2 (iLO2) management processor.



NOTE: The iLO2 RIBCL plug-in is referenced as `ilo2_ribcl` in the OpenHPI tree, and by the name `libilo2_ribcl` in all OpenHPI configuration files.

For more information and documentation on the OpenHPI project, refer to the following web sites:

- <http://www.openhpi.org>
- <http://sourceforge.net/projects/openhpi>
- <http://openhpi.sourceforge.net/manual/book1.html>

Supported Systems

The iLO2 RIBCL plug-in is supported on the following HP ProLiant Rack Mount Servers:

- DL360 G5
- DL365 G1
- DL380 G5, G6
- DL385 G2, G5

Unsupported Systems

The iLO2 RIBCL plug-in is not supported on the DL580 and DL585 HP ProLiant Rack Mount Servers.

OpenHPI Releases

The iLO2 RIBCL plug-in is included in the OpenHPI 2.12 release. For earlier OpenHPI releases, beginning with the 2.10 release, the iLO2 RIBCL patches can be downloaded from the following web site:

http://sourceforge.net/tracker/index.php?func=detail&aid=1841151&group_id=71730&atid=532254

Future enhancements and defect fixes for this plug-in are posted to the `openhpi-devel` mailing list located at:

http://sourceforge.net/mailarchive/forum.php?forum_name=openhpi-devel

You can monitor this list or perform a search for the string `ilo2_ribcl` to find relevant content in the mailing list archives.

System Requirements

The iLO2 RIBCL plug-in is installed and enabled automatically when you compile and install OpenHPI. Instructions are provided in the `openhpi/README` file. You may run into errors during the OpenHPI configuration and build process if your build system does not contain the necessary software packages.

The following section describes what you need to successfully build OpenHPI with the iLO2 RIBCL plug-in and contains information on installation and firmware requirements.

Installation Requirements

To successfully install the iLO2 RIBCL plug-in during the OpenHPI build process, you must have the following packages installed on your Management Server (host system):

- `openssl-devel` version 0.9.8a or later
- `libxml2-devel` version 2.6.23 or later

HP recommends that you use the latest version that is available for your distribution.



NOTE: You may disable the automatic build of the iLO2 RIBCL plug-in by passing the configure flag `--disable-ilo2_ribcl` during the configure process. The configuration file `./configure --disable-ilo2_ribcl` builds OpenHPI without the iLO2 RIBCL plug-in. For more information, see the *README* file that is packaged with the OpenHPI distribution.

Firmware Requirements

Verify that iLO2 firmware version 1.10 or later is installed on all target HP ProLiant Rack Mount server systems to be managed. The Lights-Out advanced pack licensing level is required to access advanced manageability features such as Power Management.

For detailed instructions on performing the firmware upgrade, see the *HP Integrated Lights-Out 2 User Guide* located at:

<http://www.hp.com/servers/lights-out>

Configuring the iLO2 RIBCL Plug-In

The OpenHPI iLO2 RIBCL plug-in is configured in the `/etc/openhpi/openhpi.conf` OpenHPI configuration file. Using your preferred text editor, edit the file and configure the iLO2 RIBCL plug-in instance.

This section contains information on the following topics:

- Setting the iLO2 Username and Password
- Modifying the iLO2 RIBCL section in the OpenHPI Configuration File

Setting the iLO2 User Name and Password

You must set up a user account on the iLO2 management processor for each HP ProLiant Rack Mount server that you want to manage. The iLO2 is configured at the factory with a default username and password. The default username and password can be found on the iLO2 Network Settings tag attached to the server. HP recommends changing the default username and password after logging in to iLO2 for the first time.

The login and password in the `/etc/openhpi/openhpi.conf` configuration file must correspond to an iLO2 local user name and password. In addition, to support any HPI API that involves power control or reset, verify the iLO2 local user name and password has the *Virtual Power and Reset* privilege.

To setup or change the login and password, refer to the “iLO2 Setup” and “Configuring iLO2” chapters in the *HP Integrated Lights-Out 2 User Guide* located at:

<http://www.hp.com/servers/lights-out>

Modifying the iLO2 RIBCL Section in the OpenHPI Configuration File

The iLO2 RIBCL plug-in supports several interfaces for configuration. The following is an example configuration stanza for the iLO2 RIBCL plug-in:

```
handler libilo2_ribcl {
    entity_root = "{RACK_MOUNTED_SERVER,8}"
    ilo2_ribcl_hostname = "x.x.x.x" # iLO2 IP address
    ilo2_ribcl_portstr = "443" # iLO2 RIBCL SSL server
    port number
    ilo2_ribcl_username = "username" # iLO2 username
    ilo2_ribcl_password = "password" # iLO2 password
}
```

You must update the entries in the /etc/openhpi/openhpi.conf configuration file for your particular configuration as follows:

- The value of `ilo2_ribcl_hostname` must be set to the TCP/IP address of the iLO2 on the system you want to manage.
- The value of `ilo2_ribcl_portstr` specifies the Web Server SSL Port used by the iLO2 RIBCL plug-in. The default configuration value is 443. Change this value only if you have changed the Web Server SSL Port configuration in iLO2.
- The value of `ilo2_ribcl_username` and `ilo2_ribcl_password` must correspond to an iLO2 local username and password.

HP ProLiant Server Resources

This section covers the following topics:

- HP ProLiant Server Model Differences
- RPT Mapping and HP ProLiant Server Entity Types
- System Chassis Resources
- Processor Resources
- Memory Resources
- Power Supply Resources
- Power Module (VRM) Resources
- Fan Resources

All removable resources use the simple hot swap model, and specify `SA_CAPABILITY_FRU` in the `ResourceCapabilities` of their Resource Presence Table entry. The System Chassis is the only resource that is not a field replaceable unit. For details on how hot swap works with HP ProLiant servers, see “Hot Swap Operations” (page 26).

The `ResourceSeverity` field in the Resource Presence Table entry for all ProLiant resources is set to `SAHPI_CRITICAL`.

HP ProLiant Server Model Differences

The OpenHPI iLO2 RIBCL plug-in communicates with the onboard iLO2 management processor to dynamically determine the resource entities. Table 1 shows the resource differences between each supported HP ProLiant Rack mount server.

Table 1 HP ProLiant Model Resource Differences

Resource	DL360 G5	DL365 G1	DL380 G5	DL385 G2
System Chassis	1	1	1	1
Processor	2	2	2	2
Memory DIMM	up to 8	up to 8	up to 8	up to 8
Power Supply	1 to 2	1 to 2	1 to 2	1 to 2
Power (VRM)	2	2	2	2
Fans	3 (fan blocks)	3 (fan blocks)	6	6

RPT Mapping and HP ProLiant Server Entity Types

The following tables outline the RPT mappings, entity type definitions, and entity path examples supported by the iLO2 RIBCL plug-in.

Table 2 RPT Mappings

Resource	Entity Path	Capabilities
HP ProLiant Rack Mount Chassis	{entity_root} {RACK_MOUNTED_SERVER,#}	SA_CAPABILITY_CONTROL SA_CAPABILITY_INVENTORY_DATA SA_CAPABILITY_POWER SA_CAPABILITY_RDR SA_CAPABILITY_RESET SA_CAPABILITY_RESOURCE SA_CAPABILITY_SENKO
Processor	{RACK_MOUNTED_SERVER,#} {PROCESSOR,#}	SA_CAPABILITY_FRU SA_CAPABILITY_INVENTORY_DATA SA_CAPABILITY_RDR SA_CAPABILITY_RESOURCE
Memory Device	{RACK_MOUNTED_SERVER,#} {MEMORY_DEVICE,#}	SA_CAPABILITY_FRU SA_CAPABILITY_INVENTORY_DATA SA_CAPABILITY_RDR SA_CAPABILITY_RESOURCE
Power Supply	{RACK_MOUNTED_SERVER,#} {POWER_SUPPLY,#}	SA_CAPABILITY_FRU SA_CAPABILITY_RESOURCE
Power Module	{RACK_MOUNTED_SERVER,#} {POWER_MODULE,#}	SA_CAPABILITY_FRU SA_CAPABILITY_RESOURCE

Table 3 HP ProLiant Server Entity Type Definitions

Entity Name	Entity Type
ProLiant Rack Mount Server Chassis	RACK_MOUNTED_SERVER
Processor	PROCESSOR
Memory Module	MEMORY_DEVICE
Power Supply Module	POWER_SUPPLY
Power Module	POWER_MODULE
Fan	COOLING_DEVICE

Table 4 Entity Path Examples

Resources	Example Entity Path
ProLiant Rack Mount Server Chassis	{RACK_MOUNTED_SERVER,9}
Processor(s)	{RACK_MOUNTED_SERVER,9}{PROCESSOR,1} {RACK_MOUNTED_SERVER,9}{PROCESSOR,2}
Memory Module	{RACK_MOUNTED_SERVER,9}{MEMORY_DEVICE,1} {RACK_MOUNTED_SERVER,9}{MEMORY_DEVICE,2}
Power Module	{RACK_MOUNTED_SERVER,9}{POWER_MODULE,1} {RACK_MOUNTED_SERVER,9}{POWER_MODULE,2}
Fan(s)	{RACK_MOUNTED_SERVER,9}{COOLING_DEVICE,1} {RACK_MOUNTED_SERVER,9}{COOLING_DEVICE,2})

System Chassis Resources

The entity location for the system chassis is specified in the `openhpi.conf` configuration file as the entity location for the `entity_root`.

The resource tag for the system chassis is constructed by combining the system model number with the system serial number and the entity location of the `entity_root` enclosed within parenthesis. For example, the following syntax specifies a resource tag for the DL360 G5 server with the number 5 as the entity location.

Example Syntax ProLiant DL360 G5 SN:MXQ73703A6 (5)

Processor Resources

The entity location for a processor resource is the slot number for that processor given by the iLO2 RIBCL plug-in.

The resource tag for a processor resource is the label value returned from the RIBCL `GET_HOST_DATA` command. It is displayed as `Proc N`, where `N` is the processor slot number.

Memory Resources

The entity location for a memory DIMM resource is the slot number for that DIMM given by the iLO2 RIBCL plug-in.

The resource tag for a memory DIMM resource is the label value returned from the RIBCL `GET_HOST_DATA` command. It is displayed as `DIMM NX`, where `N` is the slot number and `X` is a capital letter as shown in the following example syntax.

Example Syntax DIMM 2A

Future supported systems may have a different format for the DIMM resource tag.

Power Supply Resources

The entity location for the power supply resource is the bay number for that power supply given by the iLO2 RIBCL plug-in.

The resource tag for a power supply resource is the label value returned for that power supply from the RIBCL `GET_EMBEDDED_HEALTH_DATA` command. It is displayed as `Power Supply N`, where `N` is the power supply

Power Module (VRM) Resources

The entity location for a power module resource is the VRM slot number for that module given by the iLO2 RIBCL plug-in. The resource tag for a power module resource is the label value returned from the `GET_EMBEDDED_HEALTH_DATA` command. It is displayed as `VRM N`, where `N` is the slot number.

Fan Resources

The entity location for a fan resource is the fan index number given by the iLO2 RIBCL plug-in. Note, for the DL360 server and the DL365 server, the index number specifies a block of several fans.

The resource tag for a fan resource is constructed by combining the label and zone values for the fan that are returned by the `GET_EMBEDDED_HEALTH_DATA` command.

Example Syntax For DL380 and DL385 Servers:
 Fan 2 Location I/O Board

Example Syntax For DL360 and DL365 Servers:
 Fan Block 2 Location CPU

The DL360 and DL 365 Servers report information for block fans.

Resource RDR Mappings

All inventory data repositories, areas, and fields are read-only. The supported HPI inventory APIs include the following:

- `saHpiIdrInfoGet()`
- `saHpiIdrAreaHeaderGet()`
- `saHpiIdrFieldGet()`

Sensor readings are updated only during a discovery operation due to the overhead of the iLo2 communication latency.

Sensor readings are also updated with the periodic resource discovery performed by the openhpid daemon's `oh_discovery_thread_loop`, and occur approximately every three minutes. The sensor reading returned from `saHpiSensorReadingGet()` is the cached value obtained during the most recent discovery operation.

This section contains information on the following topics:

- HP ProLiant Chassis RDRs
- Processor RDRs
- Memory RDRs
- Power Supply RDRs
- Fan (Cooling Device) RDRs
- Voltage Regulator Module (VRM) RDRs
- Sample hptop Output for Supported Servers

HP ProLiant Chassis RDRs

Chassis Controls

Table 5 identifies the chassis controls available and supported by the iLO2 RIBCL plug-in. Table 6 on page 15 provides a summary of the chassis controls that are available and supported by the iLO2 RIBCL plug-in.

Table 5 Supported Controls

Control	Description
Unit Identification Light (UID) Control	<p>Unit Identification Light status can be queried using the saHpiControlGet API and the light can be turned on or off using the saHpiControlSet API.</p> <p>Valid values for the Unit Identification Light (UID) Control include:</p> <ul style="list-style-type: none"> • .. On(1) • .. Off(0)
Power Saver Control	<p>The iLO2 Power Regulator Feature on HP ProLiant Rack Mount servers allow various power modes for the systems to run. The current Power Regulator value can be queried on all supported HP ProLiant Rack Mount servers.</p> <p>Changing the Power Regulator value is fully supported on DL360 and DL380. DL365 does not support the Power Saver Set feature. DL385 supports only the HP Static Low Power Mode. The valid modes for Power Regulator Setting (Power Saver) Control include:</p> <ul style="list-style-type: none"> • OS Control Mode or Disabled Mode for iLO(1) • HP Static Low Power Mode(2) • HP Dynamic Power Savings Mode(3) • HP Static High Performance Mode(4)
Auto Power Control	<p>The <i>iLO2 Automatic Power On</i> and <i>Automatic Power On with Delay</i> features allow users to change the values to suit their needs. Valid values for the Automatic Power On include:</p> <ul style="list-style-type: none"> • Enabled with a minimum delay(1) • Disabled(2) • Enabled with random delay up to 60 seconds(3) • Enabled with 15 seconds delay(15) • Enabled with 30 seconds delay(30) • Enabled with 45 seconds delay(45) • Enabled with 60 seconds delay(60)

Table 6 Chassis Control Summary

Control	Output Type	Type
Unit Identification Light (UID) Control	SAHPI_CTRL_LED	SAHPI_CTRL_TYPE_DIGITAL
Power Saver Control	SAHPI_CTRL_GENERIC	SAHPI_CTRL_TYPE_DISCRETE
Auto Power Control	SAHPI_CTRL_GENERIC	SAHPI_CTRL_TYPE_DISCRETE

Chassis Inventory

The system chassis IDR is read-only and includes an area called SAHPI_IDR_AREATYPE_CHASSIS_INFO that contains the following four read-only fields:

Table 7 Chassis Inventory Fields

Field ID	Field Type	Value
1	SAHPI_IDR_FIELDTYPE_PRODUCT_NAME	Model number
2	SAHPI_IDR_FIELDTYPE_SERIAL_NUMBER	Serial number
3	SAHPI_IDR_FIELDTYPE_MANUFACTURER	"Hewlett Packard"
4	SAHPI_IDR_FIELDTYPE_CUSTOM	iLo2 firmware revision

The iLO2 firmware version returned by the custom Field ID 4 is expressed as:

iLo2_Firmware: <major rev>.<minor rev>

Example Chassis IDR Output

The following is an example of the chassis IDR output that is returned from the hpiinv command.

```
Resource[0] Tag: ProLiant DL385 G2 SN:2UX72901KM ( 4) has inventory capability  
{RACK_MOUNTED_SERVER:4} {ROOT:0}
```

```
RDR[30000]: Inventory, IdrId=0 ProLiant DL385 G2  
SN:2UX72901KM ( 4) Inventory
```

```
AreaId[1] Chassis Area
```

```
FieldId[1] Product Name : ProLiant DL385 G2
```

```
FieldId[2] Serial Number : 2UX72901KM
```

```
FieldId[3] Manufacturer : Hewlett Packard
```

```
FieldId[4] Custom Field : iLo2_Firmware: 1.30
```

Chassis Sensors

There are three severity type sensors located on the System Chassis resource. These sensors correspond to the system's general health, and display information given in the HEALTH_AT_A_GLANCE stanza returned by the GET_EMBEDDED_HEALTH RIBCL command.

All three sensors have the RDR's EventCtrl element set to SAHPI_SEC_PER_EVENT, which allows you to change the sensor enable, sensor event enable, and assert/deassert masks via the OpenHPI APIs. In addition, the System Chassis resource does not have the SAHPI_CAPABILITY_DEASSERTS capability set, so the assert and deassert masks can be asymmetrical.

Table 8 Chassis Sensors HPI Data

Sensor	Type	Category	Events
Fan Health	SAHPI_FAN	SAHPI_EC_SEVERITY	SAHPI_ES_OK SAHPI_ES_MAJOR_FROM_LESS SAHPI_ES_MAJOR_FROM_CRITICAL SAHPI_ES_CRITICAL
Temperature Health	SAHPI_TEMPERATURE,	SAHPI_EC_SEVERITY	SAHPI_ES_OK SAHPI_ES_CRITICAL
Power Supply Health	SAHPI_POWER_SUPPLY	SAHPI_EC_SEVERITY	SAHPI_ES_OK SAHPI_ES_MAJOR_FROM_LESS SAHPI_ES_MAJOR_FROM_CRITICAL SAHPI_ES_CRITICAL

Table 9 Chassis Sensor Values

Sensor	RIBCL Value	HP Generated Event	Sensor Reading
Fan Health	OK	SAHPI_ES_OK	0
	Degraded	SAHPI_ES_MAJOR_FROM_LESS SAHPI_ES_MAJOR_FROM_CRITICAL	1
	Failed	SAHPI_ES_CRITICAL	2
Temperature Health	OK	SAHPI_ES_OK	0
	Failed	SAHPI_ES_CRITICAL	2

Table 9 Chassis Sensor Values (continued)

Sensor	RIBCL Value	HP Generated Event	Sensor Reading
Power Supply Health	OK	SAHPI_ES_OK	0
	Degraded	SAHPI_ES_MAJOR_FROM_LESS SAHPI_ES_MAJOR_FROM_CRITICAL	1
	Failed	SAHPI_ES_CRITICAL	2

Processor RDRs

The IDR for a processor resource is read-only and includes an area called SAHPI_IDR_AREATYPE_BOARD_INFO that contains the following single, read-only field:

Table 10 Processor Inventory Field

Field ID	Field Type	Value
1	SAHPI_IDR_FIELDTYPE_CUSTOM	Processor Speed

The processor speed returned by the custom Field ID 1 is the processor's rated speed. The processor speed returned by the custom Field ID 1 is expressed as:

Speed: <speed> MHz

Example Processor IDR Output

The following is an example of the processor IDR output that is returned by the hpiinv command.

```
Resource[26] Tag: Proc 1 has inventory capability
{PROCESSOR:1} {RACK_MOUNTED_SERVER:4} {ROOT:0}
RDR[30000]: Inventory, IdrId=0 Proc 1 Inventory
AreaId[1] Board Area
    FieldId[1] Custom Field : Speed: 2200 MHz
```

Memory RDRs

The IDR for a memory resource is read-only and includes an area called SAHPI_IDR_AREATYPE_BOARD_INFO that contains the following two, read-only fields:

Table 11 Memory Inventory Fields

Field ID	Field Type	Value
1	SAHPI_IDR_FIELDTYPE_CUSTOM	Memory Size
2	SAHPI_IDR_FIELDTYPE_CUSTOM	Memory Speed

The memory size is returned by the custom Field ID 1 and is expressed as:

Size: <size> MB

The memory speed is returned by the custom Field ID 2 and is expressed as:

Size: <speed> MHz

Example Memory IDR Output

The following is an example of the memory IDR output returned from the hpiinv command:

```
Resource[28] Tag: DIMM 1A has inventory capability
{MEMORY_DEVICE:1} {RACK_MOUNTED_SERVER:4} {ROOT:0}
RDR[30000]: Inventory, IdrId=0 DIMM 1A Inventory
AreaId[1] Board Area
    FieldId[1] Custom Field : Size: 1024 MB
    FieldId[2] Custom Field : Speed: 667 MHz
```

Power Supply RDRs

Currently, the power supply resource has no additional RDRs

Fan (Cooling Device)

Currently, the fan resource has no additional RDRs.

Voltage Regulator Module (VRM) RDRs

Currently, the power module (voltage regulator) resource has no additional RDRs.

Sample hptop Output for Supported Servers

Table 12 provides sample hptop output for all supported HP ProLiant Rack Mount servers.

Table 12 Sample hptop Output

Supported Server	Output
DL360 G5	<pre>{RACK_MOUNTED_SERVER,5} +--- {RACK_MOUNTED_SERVER,5} __ Control Num: 1, Type: DIGITAL, Output Type: LED, Tag: Unit Identification Light (UID) Values: On(1)/Off(0) __ Control Num: 2, Type: DISCRETE, Output Type: GENERIC, Tag: Power Regulator Control Power Modes: Disabled(1)/Low(2)/DynamicSavings(3)/High(4) __ Control Num: 3, Type: DISCRETE, Output Type: GENERIC, Tag: Auto Power Control Delay:Min.(1)/Disabled(2)/random (3)/15 sec (15)/30 sec (30)/45 sec(45)/60 sec(60) __ Sensor Num: 1, Type: FAN, Category: SEVERITY, Tag: System fans health indicator: Ok(0)/Degraded(1)/Failed(2) __ Sensor Num: 2, Type: TEMPERATURE, Category: SEVERITY, Tag: System temperature health indicator: Ok(0)/Failed(2) __ Sensor Num: 3, Type: POWER_SUPPLY, Category: SEVERITY, Tag: System power supply health indicator: Ok(0)/Degraded(1)/Failed(2) __ Inventory Idr Num: 0, Num Areas: 1, Tag: ProLiant DL360 G5 SN:MXQ73703A6 (5) Inventory +--- {RACK_MOUNTED_SERVER,5}{PROCESSOR,1} __ Inventory Idr Num: 0, Num Areas: 1, Tag: Proc 1 Inventory +--- {RACK_MOUNTED_SERVER,5}{PROCESSOR,2} __ Inventory Idr Num: 0, Num Areas: 1, Tag: Proc 2 Inventory +--- {RACK_MOUNTED_SERVER,5}{MEMORY_DEVICE,1} __ Inventory Idr Num: 0, Num Areas: 1, Tag: DIMM 1A Inventory +--- {RACK_MOUNTED_SERVER,5}{MEMORY_DEVICE,3} __ Inventory Idr Num: 0, Num Areas: 1, Tag: DIMM 3A Inventory +--- {RACK_MOUNTED_SERVER,5}{POWER_SUPPLY,1}</pre>

Table 12 Sample hptop Output (continued)

Supported Server	Output
	 +--- { RACK_MOUNTED_SERVER, 5 } { POWER_SUPPLY, 2 } +--- { RACK_MOUNTED_SERVER, 5 } { POWER_MODULE, 1 } +--- { RACK_MOUNTED_SERVER, 5 } { POWER_MODULE, 2 } +--- { RACK_MOUNTED_SERVER, 5 } { COOLING_DEVICE, 1 } +--- { RACK_MOUNTED_SERVER, 5 } { COOLING_DEVICE, 2 } +--- { RACK_MOUNTED_SERVER, 5 } { COOLING_DEVICE, 3 } End of { RACK_MOUNTED_SERVER, 5 }

Table 12 Sample hptop Output (continued)

Supported Server	Output
DL365 G1	{RACK_MOUNTED_SERVER,1} +--- {RACK_MOUNTED_SERVER,1} __ Control Num: 1, Type: DIGITAL, Output Type: LED, Tag: Unit Identification Light (UID) Values: On(1)/Off(0) __ Control Num: 2, Type: DISCRETE, Output Type: GENERIC, Tag: Power Regulator Control Power Modes: Disabled(1)/Low(2)/DynamicSavings(3)/High(4) __ Control Num: 3, Type: DISCRETE, Output Type: GENERIC, Tag: Auto Power Control Delay:Min.(1)/Disabled(2)/random (3)/15 sec (15)/30 sec (30)/45 sec(45)/60 sec(60) __ Sensor Num: 1, Type: FAN, Category: SEVERITY, Tag: System fans health indicator: Ok(0)/Degraded(1)/Failed(2) __ Sensor Num: 2, Type: TEMPERATURE, Category: SEVERITY, Tag: System temperature health indicator: Ok(0)/Failed(2) __ Sensor Num: 3, Type: POWER_SUPPLY, Category: SEVERITY, Tag: System power supply health indicator: Ok(0)/Degraded(1)/Failed(2) __ Inventory Idr Num: 0, Num Areas: 1, Tag: ProLiant DL365 G1 SN:MXQ73604LV (1) Inventory +--- {RACK_MOUNTED_SERVER,1}{PROCESSOR,1} __ Inventory Idr Num: 0, Num Areas: 1, Tag: Proc 1 Inventory +--- {RACK_MOUNTED_SERVER,1}{PROCESSOR,2} __ Inventory Idr Num: 0, Num Areas: 1, Tag: Proc 2 Inventory +--- {RACK_MOUNTED_SERVER,1}{MEMORY_DEVICE,1} __ Inventory Idr Num: 0, Num Areas: 1, Tag: DIMM 1A Inventory

Table 12 Sample hptop Output (continued)

Supported Server	Output
	+--- {RACK_MOUNTED_SERVER,1}{MEMORY_DEVICE,2} Inventory Idr Num: 0, Num Areas: 1, Tag: DIMM 2A Inventory +--- {RACK_MOUNTED_SERVER,1}{POWER_SUPPLY,1} +--- {RACK_MOUNTED_SERVER,1}{POWER_SUPPLY,2} +--- {RACK_MOUNTED_SERVER,1}{POWER_MODULE,1} +--- {RACK_MOUNTED_SERVER,1}{POWER_MODULE,2} +--- {RACK_MOUNTED_SERVER,1}{COOLING_DEVICE,1} +--- {RACK_MOUNTED_SERVER,1}{COOLING_DEVICE,2} +--- {RACK_MOUNTED_SERVER,1}{COOLING_DEVICE,3} End of {RACK_MOUNTED_SERVER,1}

Table 12 Sample hptop Output (continued)

Supported Server	Output
DL380 G5	{RACK_MOUNTED_SERVER,7} +--- {RACK_MOUNTED_SERVER,7} __ Control Num: 1, Type: DIGITAL, Output Type: LED, Tag: Unit Identification Light (UID) Values: On(1)/Off(0) __ Control Num: 2, Type: DISCRETE, Output Type: GENERIC, Tag: Power Regulator Control Power Modes: Disabled(1)/Low(2)/DynamicSavings(3)/High(4) __ Control Num: 3, Type: DISCRETE, Output Type: GENERIC, Tag: Auto Power Control Delay:Min.(1)/Disabled(2)/random (3)/15 sec (15)/30 sec (30)/45 sec(45)/60 sec(60) __ Sensor Num: 1, Type: FAN, Category: SEVERITY, Tag: System fans health indicator: Ok(0)/Degraded(1)/Failed(2) __ Sensor Num: 2, Type: TEMPERATURE, Category: SEVERITY, Tag: System temperature health indicator: Ok(0)/Failed(2) __ Sensor Num: 3, Type: POWER_SUPPLY, Category: SEVERITY, Tag: System power supply health indicator: Ok(0)/Degraded(1)/Failed(2) __ Inventory Idr Num: 0, Num Areas: 1, Tag: ProLiant DL380 G5 SN:2UX72503WK (7) Inventory +--- {RACK_MOUNTED_SERVER,7}{PROCESSOR,1} __ Inventory Idr Num: 0, Num Areas: 1, Tag: Proc 1 Inventory +--- {RACK_MOUNTED_SERVER,7}{PROCESSOR,2} __ Inventory Idr Num: 0, Num Areas: 1, Tag: Proc 2 Inventory +--- {RACK_MOUNTED_SERVER,7}{MEMORY_DEVICE,1} __ Inventory Idr Num: 0, Num Areas: 1, Tag: DIMM 1A Inventory

Table 12 Sample hptop Output (continued)

Supported Server	Output
	+--- {RACK_MOUNTED_SERVER, 7}{MEMORY_DEVICE, 3} __ Inventory Idr Num: 0, Num Areas: 1, Tag: DIMM 3A Inventory +--- {RACK_MOUNTED_SERVER, 7}{MEMORY_DEVICE, 5} __ Inventory Idr Num: 0, Num Areas: 1, Tag: DIMM 5B Inventory +--- {RACK_MOUNTED_SERVER, 7}{MEMORY_DEVICE, 7} __ Inventory Idr Num: 0, Num Areas: 1, Tag: DIMM 7B Inventory +--- {RACK_MOUNTED_SERVER, 7}{POWER_SUPPLY, 1} +--- {RACK_MOUNTED_SERVER, 7}{POWER_SUPPLY, 2} +--- {RACK_MOUNTED_SERVER, 7}{POWER_MODULE, 1} +--- {RACK_MOUNTED_SERVER, 7}{POWER_MODULE, 2} +--- {RACK_MOUNTED_SERVER, 7}{COOLING_DEVICE, 1} +--- {RACK_MOUNTED_SERVER, 7}{COOLING_DEVICE, 2} +--- {RACK_MOUNTED_SERVER, 7}{COOLING_DEVICE, 3} +--- {RACK_MOUNTED_SERVER, 7}{COOLING_DEVICE, 4} +--- {RACK_MOUNTED_SERVER, 7}{COOLING_DEVICE, 5} +--- {RACK_MOUNTED_SERVER, 7}{COOLING_DEVICE, 6} End of {RACK_MOUNTED_SERVER, 7}

Table 12 Sample hptop Output (continued)

Supported Server	Output
DL385 G2	{RACK_MOUNTED_SERVER,4} +--- {RACK_MOUNTED_SERVER,4} __ Control Num: 1, Type: DIGITAL, Output Type: LED, Tag: Unit Identification Light (UID) Values: On(1)/Off(0) __ Control Num: 2, Type: DISCRETE, Output Type: GENERIC, Tag: Power Regulator Control Power Modes: Disabled(1)/Low(2)/DynamicSavings(3)/High(4) __ Control Num: 3, Type: DISCRETE, Output Type: GENERIC, Tag: Auto Power Control Delay:Min.(1)/Disabled(2)/random (3)/15 sec (15)/30 sec (30)/45 sec(45)/60 sec(60) __ Sensor Num: 1, Type: FAN, Category: SEVERITY, Tag: System fans health indicator: Ok(0)/Degraded(1)/Failed(2) __ Sensor Num: 2, Type: TEMPERATURE, Category: SEVERITY, Tag: System temperature health indicator: Ok(0)/Failed(2) __ Sensor Num: 3, Type: POWER_SUPPLY, Category: SEVERITY, Tag: System power supply health indicator: Ok(0)/Degraded(1)/Failed(2) __ Inventory Idr Num: 0, Num Areas: 1, Tag: ProLiant DL385 G2 SN:2UX72901KM (4) Inventory +--- {RACK_MOUNTED_SERVER,4}{PROCESSOR,1} __ Inventory Idr Num: 0, Num Areas: 1, Tag: Proc 1 Inventory +--- {RACK_MOUNTED_SERVER,4}{PROCESSOR,2} __ Inventory Idr Num: 0, Num Areas: 1, Tag: Proc 2 Inventory +--- {RACK_MOUNTED_SERVER,4}{MEMORY_DEVICE,1} __ Inventory Idr Num: 0, Num Areas: 1, Tag: DIMM 1A Inventory +--- {RACK_MOUNTED_SERVER,4}{MEMORY_DEVICE,2} __ Inventory Idr Num: 0, Num Areas: 1, Tag: DIMM 2A Inventory +--- {RACK_MOUNTED_SERVER,4}{POWER_SUPPLY,1}

Table 12 Sample hptop Output (continued)

Supported Server	Output
	+--- { RACK_MOUNTED_SERVER, 4 } { POWER_MODULE, 1 } +--- { RACK_MOUNTED_SERVER, 4 } { COOLING_DEVICE, 1 } +--- { RACK_MOUNTED_SERVER, 4 } { COOLING_DEVICE, 2 } +--- { RACK_MOUNTED_SERVER, 4 } { COOLING_DEVICE, 3 } +--- { RACK_MOUNTED_SERVER, 4 } { COOLING_DEVICE, 4 } +--- { RACK_MOUNTED_SERVER, 4 } { COOLING_DEVICE, 5 } +--- { RACK_MOUNTED_SERVER, 4 } { COOLING_DEVICE, 6 } End of { RACK_MOUNTED_SERVER, 4 }

Hot Swap Operations


This section covers information for Field Replaceable Units (FRU) Non-managed Hot Swap.

FRU Non-Managed Hot Swap

There are no managed hot swappable components in HP's ProLiant Rack Mount servers. As a result, the iLO2 RIBCL plug-in implements the simple hot swap model events, *Not Present* or *Active* as defined in the *SAF-HPI Specification for Field Replaceable Units (FRUs)*. The FRUs may include units such as CPUs, memory modules, fans, and power supplies. These FRUs can only be replaced when the system is powered down.

Figure 1 Unmanaged Hot Swap Model

Simple Hot Swap Model



Resource Events and Hot Swap Events

The Rack Mounted Server itself (the top level resource) is not a FRU and does not send resource or hot swap events. It has the SAHPI_CAPABILITY_RESOURCE bit set in its ResourceCapabilities, but does not set the SAHPI_CAPABILITY_FRU flag.

All other resources within the Rack Mount Server are FRUs, but do not support managed hot swap. These resources have the SAHPI_CAPABILITY_FRU flag set in their ResourceCapabilities, but do not have the SAHPI_CAPABILITY_MANAGED_HOTSWAP flag set. These resources support a subset of the HPI hot swap states (Active or Not Present). Some of these resources can also send resource events.

All FRU resources within the server can send hot swap events with a HotSwapState of either SAHPI_HS_STATE_ACTIVE or SAHPI_HS_STATE_NOT_PRESENT. For instance, if while the openhpid is running, a managed Rack Mount Server was shut down and one of the memory DIMMS was removed, when power to the iLo2 is restored, the plug-in would issue a hot swap event with a HotSwapState of SAHPI_STATE_NOT_PRESENT for that memory DIMM resource. If a new memory DIMM was added, the plug-in would send a hot swap event for the new MEMORY_DEVICE resource with a HotSwapState of SAHPI_HS_STATE_ACTIVE.

Many of the FRU resources can also send a resource event as well, with a ResourceEventType of either SAHPI_RESE_RESOURCE_FAILURE or SAHPI_RESE_RESOURCE RESTORED. The only resources that currently do not support these resource event types are the processor and the memory DIMMS, as the RIBCL interface currently does not pass a failure status for these two resource types.

Table 13 Events Generated by ProLiant Resources

Entity Type	Resource Event Types	Hot Swap States
RACK_MOUNTED_SERVER	—	—
PROCESSOR	—	SAHPI_HS_STATE_ACTIVE,
		SAHPI_HS_STATE_NOT_PRESENT
MEMORY_DEVICE	—	SAHPI_HS_STATE_ACTIVE,
		SAHPI_HS_STATE_NOT_PRESENT
POWER_SUPPLY	SAHPI_RESE_RESOURCE_FAILURE,	SAHPI_HS_STATE_ACTIVE,
	SAHPI_RESE_RESOURCE_RESTORED	SAHPI_HS_STATE_NOT_PRESENT
POWER_MODULE	SAHPI_RESE_RESOURCE_FAILURE,	SAHPI_HS_STATE_ACTIVE,
	SAHPI_RESE_RESOURCE_RESTORED	SAHPI_HS_STATE_NOT_PRESENT
COOLING_DEVICE	SAHPI_RESE_RESOURCE_FAILURE,	SAHPI_HS_STATE_ACTIVE,
	SAHPI_RESE_RESOURCE_RESTORED	SAHPI_HS_STATE_NOT_PRESENT

Resource Event Log

None of the resources in a ProLiant Rack Mount Server maintain resource event logs. Therefore, all resources will not have the SAHPI_CAPABILITY_EVENT_LOG flag set in their ResourceCapabilities within their RPT entry. All of the saHpiEventLog*() APIs will return SA_ERR_HPI_CAPABILITY when used with these resources.

OpenHPI Domain Event Log

The OpenHPI framework uses a Domain Event Log (DEL) to store events occurring in a domain, for all plug-ins and instances of plug-ins. The size of the DEL is configurable with a default maximum size of 10,000 events.

You can change the default maximum size using the OPENHPI_DEL_SIZE_LIMIT option in the openhpi.conf file before starting openhpid. Please note that this is a dynamically, configurable parameter. If you set OPENHPI_DEL_SIZE_LIMIT = 0, the DEL is unlimited in size.

In addition, options to save the DEL to disk using the (OPENHPI_DEL_SAVE) and set the minimum severity level of events that are saved in the DEL (OPENHPI_LOG_SEV) are provided in the openhpi.conf configuration file.

OpenHPI Domain Alarm Table

The Domain Alarm Table (DAT) stores events generated with severities greater than or equal to SAHPI_MINOR. The size of the DAT is unlimited by default, but may be restricted by using the OPENHPI_DAT_SIZE_LIMIT configuration option located in the openhpi.conf file.

OpenHPI iLO2 RIBCL Plug-In Supported APIs

Table 14 provides a list of HPI Function APIs and their associated support status and supporting modules.

Table 14 Supported APIs for iLO2 RIBCL Plug-In

HPI Function API	Support Status	Supporting Module
General		
saHpiVersionGet	Yes	OpenHPI framework
Session Management		
saHpiSessionOpen	Yes	OpenHPI framework
saHpiSessionClose	Yes	OpenHPI framework
Domain Discovery		
saHpiDiscover	Yes	iLO2 RIBCL plug-in
saHpiDomainInfoGet	Yes	OpenHPI framework
saHpiDrtEntryGet	Yes	OpenHPI framework
saHpiDomainTagSet	Yes	OpenHPI framework
Resource Presence Table		
saHpiRptEntryGet	Yes	OpenHPI framework
saHpiRptEntryGetByResourceId	Yes	OpenHPI framework
saHpiResourceSeveritySet	Yes	iLO2 RIBCL plug-in
saHpiResourceTagSet	Yes	iLO2 RIBCL plug-in
saHpiResourceIdGet	Yes	OpenHPI framework
saHpiGetIdByEntityPath	Yes	OpenHPI framework
saHpiGetChildEntityPath	Yes	OpenHPI framework
Event Log Management		
saHpiEventLogInfoGet	Yes	OpenHPI framework
saHpiEventLogEntryGet	Yes	OpenHPI framework
saHpiEventLogEntryAdd	Yes	OpenHPI framework
saHpiEventLogClear	Yes	OpenHPI framework
saHpiEventLogTimeGet	Yes	OpenHPI framework
saHpiEventLogTimeSet	Yes	OpenHPI framework
saHpiEventLogStateGet	Yes	OpenHPI framework

Table 14 Supported APIs for iLO2 RIBCL Plug-In (continued)

HPI Function API	Support Status	Supporting Module
saHpiEventLogStateSet	Yes	OpenHPI framework
saHpiEventLogOverflowReset	Yes	OpenHPI framework
saHpiEventLogCapabilitiesGet	Yes	OpenHPI framework
Event		
saHpiSubscribe	Yes	OpenHPI framework
saHpiUnsubscribe	Yes	OpenHPI framework
saHpiEventGet	Yes	—
saHpiEventAdd	Yes	OpenHPI framework
Domain Alarm Table		
saHpiAlarmGetNext	Yes	OpenHPI framework
saHpiAlarmGet	Yes	OpenHPI framework
saHpiAlarmAcknowledge	Yes	OpenHPI framework
saHpiAlarmAdd	Yes	OpenHPI framework
saHpiAlarmDelete	Yes	OpenHPI framework
Resource Data Record Management		
saHpiRdrGet	Yes	OpenHPI framework
saHpiRdrGetByInstrumentId	Yes	OpenHPI framework
Sensor		
saHpiSensorReadingGet	Yes	iLO2 RIBCL plug-in
saHpiSensorThresholdsGet		—
saHpiSensorThresholdsSet		—
saHpiSensorTypeGetd	Yes	OpenHPI framework
saHpiSensorEnableGet	Yes	iLO2 RIBCL plug-in
saHpiSensorEnableSet	Yes	iLO2 RIBCL plug-in
saHpiSensorEventEnableGet	Yes	iLO2 RIBCL plug-in
saHpiSensorEventEnableSet	Yes	iLO2 RIBCL plug-in
saHpiSensorEventMasksGet	Yes	iLO2 RIBCL plug-in
saHpiSensorEventMasksSet	Yes	iLO2 RIBCL plug-in
Control		
saHpiControlTypeGet	Yes	OpenHPI framework
saHpiControlGet	Yes	iLO2 RIBCL plug-in
saHpiControlSet	Yes	—
Inventory Data Repository		
saHpiIdrInfoGet-	Yes	iLO2 RIBCL plug-in
saHpiIdrAreaHeaderGet	Yes	iLO2 RIBCL plug-in
saHpiIdrAreaAdd	No. The plug-in supports only read-only IDRs.	—

Table 14 Supported APIs for iLO2 RIBCL Plug-In (continued)

HPI Function API	Support Status	Supporting Module
saHpiIdrAreaDelete	No. The plug-in supports only read-only IDR.s.	—
saHpiIdrAreaAddById	No. The plug-in supports only read-only IDR.s.	—
saHpiIdrFieldGet	Yes	iLO2 RIBCL plug-in
saHpiIdrFieldAdd	No. The plug-in supports only read-only IDR.s.	—
saHpiIdrFieldAddById	No. The plug-in supports only read-only IDR.s.	—
saHpiIdrFieldSet	No. The plug-in supports only read-only IDR.s.	—
saHpiIdrFieldDelete	No. The plug-in supports only read-only IDR.s.	—
saHpiResourceLoadIdGet	No. The plug-in supports only read-only IDR.s.	—
saHpiResourceLoadIdSet	No. The plug-in supports only read-only IDR.s.	—
Watchdog Timer		
saHpiWatchdogTimerGet	No. RIBCL does not export Announcer controls.	—
saHpiWatchdogTimerSet	No. RIBCL does not export Announcer controls.	—
saHpiWatchdogTimerReset	No. RIBCL does not export Announcer controls.	—
saHpiAnnunciatorGetNext	No. RIBCL does not export Announcer controls.	—
saHpiAnnunciatorGet	No. RIBCL does not export Announcer controls.	—
saHpiAnnunciatorAcknowledge	No. RIBCL does not export Announcer controls.	—
saHpiAnnunciatorAdd	No. RIBCL does not export Announcer controls.	—
saHpiAnnunciatorDelete	No. RIBCL does not export Announcer controls.	—
saHpiAnnunciatorModeGet	No. RIBCL does not export Announcer controls.	—
saHpiAnnunciatorModeSet	No. RIBCL does not export Announcer controls.	—
Hotswap Management		
saHpiHotSwapPolicyCancel	No. ProLiant Rack Mounts do not have any hot swap components.	—
saHpiResourceActiveSet	No. ProLiant Rack Mounts do not have any hot swap components.	—
saHpiResourceInactiveSet	No. ProLiant Rack Mounts do not have any hot swap components.	—
saHpiResourceFailedRemove	No. ProLiant Rack Mounts do not have any hot swap components.	—
saHpiAutoInsertTimeoutGet	No. ProLiant Rack Mounts do not have any hot swap components.	—
saHpiAutoInsertTimeoutSet	No. ProLiant Rack Mounts do not have any hot swap components.	—
saHpiAutoExtractTimeoutGet	No. ProLiant Rack Mounts do not have any hot swap components.	—
saHpiAutoExtractTimeoutSet	No. ProLiant Rack Mounts do not have any hot swap components.	—
saHpiHotSwapStateGet	No. ProLiant Rack Mounts do not have any hot swap components.	—

Table 14 Supported APIs for iLO2 RIBCL Plug-In (continued)

HPI Function API	Support Status	Supporting Module
saHpiHotSwapActionRequest	No. ProLiant Rack Mounts do not have any hot swap components.	—
saHpiHotSwapIndicatorStateGet	No. ProLiant Rack Mounts do not have any hot swap components.	—
saHpiHotSwapIndicatorStateSet	No. ProLiant Rack Mounts do not have any hot swap components.	—
Configuration		
saHpiParmControl	No. ProLiant Rack Mounts do not have any configurable components.	—
Reset		
saHpiResourceResetStateGet	Yes. HP ProLiant Rack Mount Servers do not support pulsed reset and the only valid value this API returns is:SAHPI_RESET_DEASSERT	iLO2 RIBCL plug-in
saHpiResourceResetStateSet	Yes. Supports cold and warm reset.	iLO2 RIBCL plug-in
Power		
saHpiResourcePowerStateGet	Yes	iLO2 RIBCL plug-in
saHpiResourcePowerStateSet	Yes	iLO2 RIBCL plug-in